1-CN012 Product Data Sheet

MD® 1-CN012 Flexible UV/Visible Light-Curable Adhesive for Treated Silicone

APPLICATIONS

- Tube Sets & Fittings
- Facemasks

FEATURES

- UV/Visible Light Cure
- Very Flexible

RECOMMENDED SUBSTRATES

- Surface-Treated Platinum & **Peroxide-Cured Silicone**
- PΙ
- PPO
- PVC
- PU

BIOCOMPATIBILITY

ISO 10993-5 Cytotoxicity

Dymax MD® 1-CN012 adhesive is designed for fast bonding of plastics typically used in the manufacture of medical devices. Dymax MD Medical Device Adhesives are solvent free and cure upon exposure to UV and visible light between 300-500 nm. Their ability to cure in seconds enables faster processing, greater output, and lower processing costs. When cured with Dymax light-curing spot lamps, focused-beam lamps, or flood lamps, they deliver optimum speed and performance for medical device assembly. Dymax lamps offer the optimum balance of UV and visible light for the fastest, deepest cures. This product is in full compliance with the RoHS directives 2015/863/EU.

UNCURED PROPERTIES *			
Property	Value	Test Method	
Solvent Content	No Nonreactive Solvents	N/A	
Chemical Class	Acrylated Urethane	N/A	
Appearance	Colorless Transparent Gel	N/A	
Soluble in	Organic Solvents	N/A	
Density, g/ml	1.06	ASTM D1875	
Viscosity, cP (20 rpm)	1,300 (nominal)	ASTM D1084	

CURED MECHANICAL PROPERTIES *				
Property	Value	Test Method		
Durometer Hardness	D30	ASTM D2240		
Tensile at Break, MPa [psi]	750 [5.2]	ASTM D638		
Elongation at Break, %	140	ASTM D638		
Modulus of Elasticity, MPa [psi]	730 [5.0]	ASTM D638		

OTHER CURED PROPERTIES *				
Property	Value	Test Method		
Boiling Water Absorption, % (2 hr)	1.1	ASTM D570		
Water Absorption, % (25°C, 24 hr)	1.0	ASTM D570		
Linear Shrinkage, %	1.0	ASTM D2566		

Not Specifications N/A Not Applicable

CURING GUIDELINES

Fixture time is defined as the time to develop a shear strength of 0.1 N/mm2 [10 psi] between glass slides. Actual cure time typically is 3-to-5 times fixture time.

Dymax Curing System (Intensity)	Fixture Time or Belt Speed ^B
2000-EC (50 mW/cm ²) ^A	1 s
5000-EC (200 mW/cm ²) ^A	1 s
BlueWave® 75 (5.0 W/cm²) ^A	1 s
BlueWave® 200 (10 W/cm²) ^A	0.5 s
UVCS Conveyor with one 5000-EC (200 mW/cm²) ^C	6.1 m/min [20 ft/min]
UVCS Conveyor with Fusion F300S (2.5 W/cm²) ^C	8.2 m/min [27 ft/min]

- Α Intensity was measured over the UVA range (320-395 nm) using a Dymax
- Curing through light-blocking substrates may require longer cure times if they block wavelengths used for curing (320-450 nm). These fixture times/speeds are typical for curing thin films through 100% light-B transmitting substrates.
- At 53 mm [2.1 in] focal distance. Maximum speed of conveyor is 8.2 m/min [27 ft/min]. Intensity was measured over the UVA range (320-395 nm) using the Dymax ACCU-CAL $^{\rm TM}$ 160 Radiometer. C



REV 11/04/2020

© 2008-2020 Dymax Corporation. All rights reserved. All trademarks in this guide, except where noted, are the property of, or used under license by Dymax Corporation, U.S.A

Technical Data Collection Prior to 2008

Dymax Corporation +1.860.482.1010 | info@dymax.com | www.dymax.com

Dymax Europe GmbH

49 611.962.7900 | info_de@dymax.com | www.dymax.de

Dymax Engineering Adhesives Ireland Ltd. +353 21.237.3016 | info_ie@dymax.com | www.dymax.ie

Dymax Oligomers & Coatings +1.860.626.7006 | info_oc@dymax.com | www.dymax-oc.com

Dymax UV Adhesives & Equipment (Shanghai) Co. Ltd. +86.21.37285759 | dymaxasia@dymax.com | www.dymax

Dymax UV Adhesives & Equipment (Shenzhen) Co. Ltd. +86.755.83485759 | dymaxasia@dymax.com | www.dymax

Dymax Asia (H.K.) Limited +852.2460.7038 | dymaxasia@dymax.com | www.dymax.com.cn

Dymax Asia Pacific Pte. Ltd.

+65.6752.2887 | info_ap@dymax.com | www.dymax.com.cn

Dymax Korea LLC +82.31.608.3434 | info_kr@dymax.com | www.dymax.com/kr



MD® MEDICAL DEVICE ADHESIVES

1-CN012 Product Data Sheet

OPTIMIZING PERFORMANCE AND HANDLING

- This product cures with exposure to UV and visible light. Exposure
 to ambient and artificial light should be kept to a minimum before
 curing. Dispensing components including needles and fluid lines
 should be 100% light blocking, not just UV blocking.
- All bond surfaces should be clean and free from grease, mold release, or other contaminants prior to dispensing the adhesive.
- Cure speed is dependent upon many variables, including lamp intensity, distance from the light source, required depth of cure, bond gap, and percent light transmission of the substrate.
- 4. Oxygen in the atmosphere may inhibit surface cure. Surfaces exposed to air may require high-intensity (>100 mW/cm²) UV light to produce a dry surface cure. Flooding the bond area with an inert gas, such as nitrogen, can also reduce the effects of oxygen inhibition.
- Parts should be allowed to cool after cure before testing and subjecting to any loads.
- 6. In rare cases, stress cracking may occur in assembled parts. Three options may be explored to eliminate this problem. One option is to heat anneal the parts to remove molded-in stresses. A second option is to open the gap between mating parts to reduce stress caused by an interference fit. The third option is to minimize the amount of time the liquid adhesive remains in contact with the substrate(s) prior to curing.
- Light curing generally produces some heat. If necessary, cooling fans can be placed in the curing area to reduce the heating effect on components.
- At the point of curing, an air exhaust system is recommended to dissipate any heat and vapors formed during the curing process.

DISPENSING THE ADHESIVE

This material may be dispensed with a variety of manual and automatic applicators or other equipment as required. Questions relating to dispensing and curing systems for specific applications should be referred to Dymax Application Engineering.

CLEANUP

Uncured material may be removed from dispensing components and parts with organic solvents. Cured material will be impervious to many solvents and difficult to remove. Cleanup of cured material may require mechanical methods of removal.

PERFORMANCE AFTER TEMPERATURE EXPOSURE

Dymax light-curable materials typically have a lower thermal limit of -54°C [-65°F] and an upper limit of 150°C [300°F]. Many Dymax products can withstand temperatures outside of this range for short periods of time. Please contact Dymax Application Engineering for assistance.

BIOCOMPATIBILITY

Polymerized Dymax MD® Medical Device adhesives are biocompatibility tested in accordance with ISO 10993 and/or USP Class VI. The completed tests are listed on each product data sheet. These adhesives have not been tested for prolonged or permanent implantation and are only intended for use in short-term (<29 days) or single-use disposable-device applications. Dymax does not authorize their use in long-term implant applications

STERILIZATION

Compatible sterilization methods include gamma irradiation and ethylene oxide. Sterilization by autoclaving may be limited to certain applications. It remains the user's obligation to ascertain the effect of sterilization on the cured adhesive

GENERAL INFORMATION

This product is intended for industrial use only. Keep out of the reach of children. Avoid breathing vapors. Avoid contact with skin, eyes, and clothing. Wear impervious gloves. Repeated or continuous skin contact with uncured material may cause irritation. Remove material from skin with soap and water. Never use organic solvents to remove material from skin and eyes. For more information on the safe handling of this material, please refer to the Safety Data Sheet before use.

The data provided in this document are based on historical testing that Dymax performed under laboratory conditions as they existed at that time and are for informational purposes only. The data are neither specifications nor guarantees of future performance in a particular application. Dymax does not guarantee that this product's properties are suitable for the user's intended purpose.

Numerous factors—including, without limitation, transport, storage, processing, the material with which the product is used, and the ultimate function or purpose for which the product was obtained—may affect the product's performance and/or may cause the product's actual behavior to deviate from its behavior in the laboratory. None of these factors are within Dymax's control. Conclusions about the behavior of the product under the user's particular conditions, and the product's suitability for a specific purpose, cannot be drawn from the information contained in this document

It is the user's responsibility to determine (i) whether a product is suitable for the user's particular purpose or application and (ii) whether it is compatible with the user's intended manufacturing process, equipment, and methods. Under no circumstances will Dymax be liable for determining such suitability or compatibility. Before the user sells any item that incorporates Dymax's product, the user shall adequately and repetitively test the item in accordance with the user's procedures and protocols. Unless specifically agreed to in writing, Dymax will have no involvement in, and shall under no circumstances be liable for, such testing.

Dymax makes no warranties, whether express or implied, concerning the merchantability of this product or its fitness for a particular purpose. Nothing in this document should be interpreted as a warranty of any kind. Under no circumstances will Dymax be liable for any injury, loss, expense or incidental or consequential damage of any kind allegedly arising in connection with the user's handling, processing, or use of the product. It is the user's responsibility to adopt appropriate precautions and safeguards to protect persons and property from any risk arising from such handling, processing, or use.

The specific conditions of sale for this product are set forth in Dymax's <u>General Terms & Conditions of Sale</u>. Nothing contained herein shall act as a representation that the product use or application is free from patents owned by Dymax or any others. Nothing contained herein shall act as a grant of license under any Dymax Corporation Patent.

Except as otherwise noted, all trademarks used herein are trademarks of Dymax. The "®" symbol denotes a trademark that is registered in the U.S. Patent and Trademark Office.

The contents of this document are subject to change. Unless specifically agreed to in writing, Dymax shall have no obligation to notify the user about any change to its content.