

EC Light Shield (PN 41175) Door Interlock Installation





Figure 1. Light Shield (PN 41175) with Door Interlock Kit (PN 41166) (shown upside down)


- 1. Turn off the power and remove all cables from the Light Shield.
- 2. Remove the Reflector and Shutter from the top of the Light Shield. Place the Light Shield on its side.
- 3. Remove the five screws from the bottom of the Light Shield (Figure 2).
- 4. Attach the Magnetic Switch to the bottom of the housing using two M3 x 8-mm screws (Figure 3).



Figure 2. Remove Screws







Note: Check that the Magnetic Switch and the Magnetic Actuator are aligned.

- 7. Plug the connector to the power jack at the back of the unit. (Figure 6)
- 8. Turn the unit back over to the working orientation and reinstall the Shutter and Reflector.

Figure 3. Magnetic Switch



Figure 4. Interlock Switch Cable



Figure 5. Install Magnetic Actuator



Figure 5. Install Magnetic Actuator



© 2013 Dymax Corporation. All rights reserved. All trademarks in this guide, except where noted, are the property of, or used under license by Dymax Corporation, U.S.A.

Please note that most dispensing and curing system applications are unique. Dymax does not warrant the fitness of the product for the intended application. Any warranty applicable to the product, its application and use is strictly limited to that contained in Dymax's standard Conditions of Sale. Dymax recommends that any intended application be evaluated and tested by the user to insure that desired performance criteria are satisfied. Dymax is willing to assist users in their performance testing and evaluation by offering equipment trial rental and leasing programs to assist in such testing and evaluations. Data sheets are available for valve controllers or pressure pots upon request. QS069 12/18/2013