

BlueWave[®] MX-150 4-Pole Lightguide Adapter Installation Instructions

1. Before starting, disconnect power to the unit.
2. Lay the Emitter on its side and position it so you can access the Lightguide Mount (Figure 1).




Figure 1

3. Using a 2-mm Allen Wrench, remove the two M3 Screws and the Lightguide Adapter from the Emitter (Figure 2).




Figure 2

- Using the M3 Screws removed in Step 3, attach the 4-Pole Lightguide Adapter to the Emitter.




Figure 3

- The unit can now be used with a 4-Pole Lightguide.

NOTE: Once a Lightguide is inserted, a 2-mm Allen Wrench can be used to tighten the Set Screw (Figure 4) to secure the Lightguide in place. **Do not overtighten the Set Screw as overtightening can cause damage.**




Figure 4



© 2017 Dymax Corporation. All rights reserved. All trademarks in this guide, except where noted, are the property of, or used under license by Dymax Corporation, U.S.A. Please note that most dispensing and curing system applications are unique. Dymax does not warrant the fitness of the product for the intended application. Any warranty applicable to the product, its application and use is strictly limited to that contained in Dymax's standard Conditions of Sale. Dymax recommends that any intended application be evaluated and tested by the user to ensure that desired performance criteria are satisfied. Dymax is willing to assist users in their performance testing and evaluation by offering equipment trial rental and leasing programs to assist in such testing and evaluations. Data sheets are available for valve controllers or pressure pots upon request. QS082 12/13/2017

Dymax Corporation
+1.860.482.1010 | info@dymax.com
www.dymax.com

Dymax Europe GmbH
+49 611.962.7900 | info_de@dymax.com
www.dymax.de

Dymax Engineering Adhesives Ireland Ltd.
+353 21.237.3016 | info_ie@dymax.com
www.dymax.ie

Dymax Oligomers & Coatings
+1.860.626.7006 | info_oc@dymax.com
www.dymax-oc.com

Dymax UV Adhesives & Equipment (Shanghai) Co. Ltd.
+86.21.37285759 | dymaxasia@dymax.com
www.dymax.com.cn

Dymax UV Adhesives & Equipment (Shenzhen) Co. Ltd.
+86.755.83485759 | dymaxasia@dymax.com
www.dymax.com.cn

Dymax Asia (H.K.) Limited
+852.2460.7038 | dymaxasia@dymax.com
www.dymax.com.cn

Dymax Asia Pacific Pte. Ltd.
+65.6752.2887 | info_ap@dymax.com
www.dymax-sg.com

Dymax Korea LLC
+82.2.784.3434 | info_kr@dymax.com
www.dymax.com/kr